TO THE POINT ABOUT INDUSTRIAL CRANE SAFETY Review Quiz

NameDate	
Pl	ease provide answers to the following to show how well you understand the information presented during this program.
1.	When testing the controls during the pre-operational inspection, the tests should be performed with no load.
a.	True
b.	False
2.	The most commonly used lifting devices are
a.	Chains
b.	Wire rope slings
c.	Web slings
3.	A wire rope sling must be removed from service if you find during its inspection.
	More than five broken wires within one lay
	More than 10 or more broken wires at random
	It is missing its capacity tag
d.	All of the above
4.	Links of a chain that has been overloaded will be bent slightly
	Inward
b.	Outward
5.	Which type of hitch is formed by passing one end of a sling through another and attaching it to the crane hook?
a.	Vertical hitch
	Choker hitch
c.	Basket hitch
6.	The amount of force placed on a sling increases greatly as the horizontal sling angle gets
	Larger
b.	Smaller
	Once you have a load balanced properly, you should leave it suspended off the floor about 30 seconds to ensure the ane's brakes are holding and functioning properly.
a.	True
b.	False
8.	When moving a load, it should be raised as high as possible off the floor or ground.
a.	True
b.	False
9.	A suspended load should never be left unattended.
a.	True
b.	False

ANSWERS TO THE REVIEW QUESTIONS

- 1. a
- 2. c
- 3. d
- 4. a
- 5. b
- 6. b
- 7. a
- 8. b
- 9. a